

- If food and/or beverages are left in the container longer than 24 hours, or you suspect spoilage, use caution when opening the container. Food and/or beverage spoilage can cause pressure inside the container to build, possibly leading to the forceful ejection of the stopper or contents. In such circumstances, before attempting to open the container, ENSURE THE OPENING IS POINTED AWAY FROM THE USER OR OTHER PERSONS TO AVOID INJURY.

Thermos brand quality guarantee

This guarantee is warranted by alfi GmbH Germany. The Thermos brand quality guarantee is valid in addition to country-specific warranty claims. alfi guarantees the material and workmanship for 2 years after the date of purchase. In the case of a complaint, please contact the dealer who sold the product. Please keep the purchase receipt, which is mandatory for the processing. The guarantee does not cover damages caused by improper handling. The guarantee also becomes invalid in case of faults or defects arising from repairs and/or modifications carried out by unauthorised third parties.

alfi GmbH
Ernst-Abbe-Str. 14
D-97877 Wertheim
www.thermos.eu

THERMOS is a registered trademark in over 115 countries.

THERMOcafé™
by **THERMOS**

THERMOPRO ISOLIER-TRINKBECHER
0,4 l

THERMOPRO INSULATED
DRINKING MUG
0,4 l



www.thermos.eu

THERMOS is a registered trademark in over 115 countries.

DE

Benutzerhinweise

Vor dem ersten Gebrauch mit warmem Wasser und etwas Spülmittel ausspülen und gut belüftet trocknen lassen. Nach jedem Gebrauch Becher und Verschluss mit warmem Wasser und etwas Spülmittel ausspülen, trocknen lassen und stets geöffnet aufbewahren. Zur einfachen Reinigung kann der Verschluss zerlegt werden.

Es wird die Reinigung von Hand empfohlen. Außen ein feuchtes weiches Tuch verwenden, keine kratzenden Bürsten oder Scheuerschwämme! Für hartnäckige Verschmutzungen empfehlen wir Natron in heißem Wasser aufzulösen und über Nacht im Gefäß stehen zu lassen. Gefäß dabei nicht verschließen. Nicht ins Wasser eintauchen, keine Bleichmittel oder chlorhaltige Reiniger verwenden.

Zum Befüllen den Deckel vollständig abschrauben, danach wieder fest zuschrauben. Mug max. bis zu ca. 3/4 befüllen. Die optimale Isolierleistung wird durch vorheriges Ausspülen mit kaltem Wasser bei kalten Getränken oder mit heißem Wasser bei heißen Getränken erzielt.

Sicherheitshinweise: Nur unter Aufsicht eines Erwachsenen verwenden. Nicht unbeaufsichtigt in Kinderhänden lassen. Um die Verletzungsgefahr zu vermeiden, sollten Kinder mit dem Produkt nicht rennen oder gehen. Keine Milchprodukte oder

Babynahrung warmhalten, Gefahr von Bakterienwachstum! Keine Eiswürfel, Trockeneis oder kohlenensäurehaltige Getränke. Gefäß nur für Lebensmittel geeignet. Leicht verderbliche Produkte sollten nicht länger als notwendig im Gefäß verbleiben. Essen Sie stets vorsichtig aus dem Gefäß und füllen Sie es nicht zu voll: **Verbrühungsgefahr!**

Thermos Qualitätsgarantie

Diese Garantie wird durch die alfi GmbH Deutschland gewährt. Neben den länderspezifischen Gewährleistungsansprüchen gilt die Thermos Qualitätsgarantie. alfi gewährt ab Kaufdatum 2 Jahre Garantie auf Material und Verarbeitung. Im Falle einer Reklamation wenden Sie sich bitte an den Händler, bei dem das Produkt erworben wurde. Bitte bewahren Sie den Kaufbeleg auf, dieser wird zwingend für die Abwicklung benötigt. Auf selbst verursachte Schäden, die auf unsachgemäße Handhabung zurückzuführen sind, besteht kein Garantieanspruch. Die Garantieverpflichtung erlischt ebenfalls, wenn Fehler oder Mängel entstehen, die auf Reparaturen und Abänderungen durch nicht autorisierte Dritte zurückzuführen sind.

alfi GmbH
Ernst-Abbe-Str. 14
D-97877 Wertheim
www.thermos.eu
THERMOS ist eine eingetragene Marke in über 115 Ländern.

EN

CARE AND USE

- Before first use, and as soon as possible after each use, wash all parts with warm, soapy water. Rinse thoroughly and allow time to dry.
- The container should be periodically cleaned. The best results are obtained using a mixture of water and bicarbonate of soda or washing up liquid. Rinse thoroughly afterwards. DO NOT put the stopper/lid on whilst using this cleaning method. Soaking overnight produces excellent results. Always rinse before re-use.
- Never use in a dishwasher to clean, hand washing is recommended for best results.
- DO NOT immerse in water.
- DO NOT use abrasive cleaners or scrubbers since they may dull the finish.
- DO NOT use bleach or cleaners containing chlorine on any parts of the product.
- Pre-heat or pre-cool the container with water to ensure efficient use and to reduce the risk of breakage of the glass filler. Attach lid, let stand 5 to 10 minutes, and empty. Never use microwave or conventional ovens for this purpose.
- DO NOT use on the stove top.
- DO NOT use tools or devices to force the container to open.
- If you are unable to open the container using hand pressure, dispose of it at your local waste facility.

CAUTION

- Use only with adult supervision when product contains hot liquids or hot foods – hot liquids or hot foods can scald user.
- Never leave child unattended while using this product.
- To avoid possible injury, do not let child walk or run with product.
- Always test temperature of food or liquid before feeding to your child.
- DO NOT overfill product. Hot liquids or foods can scald user.
- DO NOT drink directly from the product or from the stopper (except products equipped with a direct drink lid).
- Check the stopper periodically. A worn stopper may cause the product to leak. Leakage of hot liquids may scald user.
- In order to minimise bacterial growth, do not use to keep warm milk products or baby food. Contents that spoil easily should not be kept in the product for prolonged periods.
- DO NOT use to store or carry carbonated drinks or dry ice. May cause stopper and contents to eject forcefully or leak.
- To prevent overflow, DO NOT fill above the bottom of the stopper. Hot liquids may scald user if overflow occurs.
- In general, food and/or beverages should not be left in the container for longer than 24 hours. The rate at which food and/or beverages spoil depends on several factors, however. Certain foods and/or beverages, such as dairy and tomato-based foods and/or beverages, for example, may start to spoil sooner.